



INSTALLATION HELP

STEP 1 **1** IMPORTANT: ALWAYS START WITH CLEAN PLASTICS.

TO CLEAN USE ISOPROPYL ALCOHOL
(OR SIMILAR PRODUCT THAT LEAVES NO RESIDUE)

ENSURE THE PLASTICS ARE THOROUGHLY DRIED BEFORE INSTALLATION

DO NOT USE MINERAL TURPENTINE OR OTHER CLEANERS

DO NOT USE HEAT GUNS



STEP 2 **2** USE A HAIRDRYER DURING INSTALL TO KEEP GRAPHICS WARM (NOT HOT) SO THEY ARE MORE PLIABLE

NOTE: WARMTH THROUGH THE GRAPHICS WILL ALLOW FOR EASIEST
INSTALL, AS GLUE IS SUPPLE WHEN WARM, AND WILL BEGIN BONDING
WITH PLASTICS ONCE IT COOLS

NOTE: DUE TO STRONG PROPERTIES OF THE GLUE, IF POSSIBLE AVOID
MISPLACING GRAPHICS AND HAVING TO REMOVE AND REPOSITION THEM.
IF REPOSITIONING IS ESSENTIAL, ENSURE THE GRAPHIC IS WARM.



STEP 3 **3**

CUT A 10MM STRIP OFF THE BACKING PAPER ON THE END OF THE GRAPHIC,
LINE UP ALL BOLT HOLES AND STICK DOWN. SLOWLY PEEL OFF BACKING
PAPER IN 10MM INCREMENTS RUBBING DOWN THE GRAPHIC WITH YOUR
THUMBS, ENSURING YOU REMOVE ANY AIR BUBBLES. ENSURE AS YOU
MOVE ALONG THE GRAPHICS IT IS ALIGNED WITH THE PLASTICS.



STEP 4 **4**

ALWAYS TRIM ALL EDGES THAT OVERHANG OR LIFT, AS IF THE GRAPHIC IS
NOT ALIGNED CORRECTLY IT WILL GET DIRT UNDERNEATH AND MAY CAUSE
THE GRAPHIC TO LIFT. ALSO RETURN TO ALL GRAPHICS AND REAPPLY
PRESSURE AGAIN TO ENSURE THEY ARE APPROPRIATELY STUCK.



STEP 5 **5**

ALWAYS ALLOW AT LEAST 48 HOURS FOR THE STICKER TO BOND
CORRECTLY TO THE PLASTIC BEFORE RIDING OR WASHING YOUR BIKE.

48h

REMOVAL

FOR EASIEST AND CLEANEST REMOVAL OF MX INK GRAPHICS IT IS RECOMMENDED THAT PLASTICS AND GRAPHICS ARE HEATED UP SO THEY ARE NOTICEABLY HOT (CAN USE HEAT GUNS/HAIRDRYERS/HEATERS). THIS WILL ASSIST IN THE FULL REMOVAL OF THE GRAPHICS AND GLUE.



INSTALLATION HELP

JERSEY PRINT PLEASE NOTE: YOUR JERSEY PRINT WILL HAVE A CLEAR BACKING AND A CLEAR PLASTIC FRONT.

YOU NEED TO PEEL OFF THE BACKING PLASTIC TO START.

1. PLACE JERSEY PRINT ON A FLAT SURFACE (THAT CAN WITHSTAND HEAT OF AN IRON)
2. PEEL AWAY FROSTED PLASTIC BACKING SHEET FROM JERSEY PRINT
3. PLACE JERSEY PRINT IN ALIGNED POSITION ON JERSEY
4. PLACE BAKING PAPER OVER FRONT OF JERSEY PRINT TO PROTECT FROM DAMAGE
5. HAVE IRON ON COTTON SETTING OR SIMILAR AND ALLOW IT TO HEAT UP (ENSURE SETTING IS DRY HEAT)
6. ONCE IRON IS HEATED, PRESS IRON ON ALL SECTIONS OF JERSEY PRINT TO ENSURE GLUE IS MELTED AND STICKS TO THE JERSEY WHILE FOCUSING ON SMOOTH APPLICATION ON ALL AREAS. (CAN BE UP TO 20 SECONDS ON EACH AREA)
7. ENSURE A FOCUS ON SHARP CORNERS AND EDGING TO AVOID LIFTING AND TEARING
8. DON'T WORRY IF WRINKLES APPEAR ON THE FRONT LAMINATE, THIS IS PART OF THE PROCESS
9. ONCE COMPLETED PEEL AWAY FRONT LAMINATE SLOWLY AND CAREFULLY, ENSURING NO EDGING IS LIFTED, IF SO RE-IRON PROBLEM AREAS WHILST LAMINATE IS STILL COVERING
10. AFTER FRONT LAMINATE IS PEELED, PLACE BAKING PAPER OVER THE FRONT OF JERSEY PRINT AND IRON OUT ANY WRINKLES THAT MAY EXIST

YOU ARE NOW COMPLETED



GRAPHIC KITS



JERSEY PRINTS



SEAT COVERS



[WWW.MXINK.COM.AU](http://www.mxink.com.au)



MX INK



@MXINKRACING